

Connecting a Mac to a classroom projector

- Make sure the video input is connected securely on both ends (a adaptor will be needed to connect Macs, these are available either at the HRC or at the helpdesk); if they want sound, the sound must also be connected separately
- If it is not displaying, go to the Apple menu > System Preferences > Displays and hit the “Detect Displays” button
- If something is showing on the projected screen, but it is not the same as what is on the computer screen, click the “Mirror displays” box
- If the size of windows/fonts/etc is crazy, try a different resolution. The recommended resolution is 1024x768

Connecting a PC to a classroom projector

- Make sure the video input is connected securely on both ends; if they want sound, the sound must also be connected separately
- If it is not displaying, restart the computer
- To check to see if the computer is detecting the projector, go to Start > Control Panel > Display > Settings
- If something is showing on the projected screen, but it is not the same as what is on the computer screen make sure the “extend screen” box is unchecked
- If the size of windows/fonts/etc is crazy, try a different resolution. The recommended resolution is 1024x768